




# TOP AND CONSOLE PARTS

For Models: WED9200SQ0

(White)

ELECTRIC DRYER



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

# TOP AND CONSOLE PARTS

For Models: WED9200SQ0

(White)


Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION
1		Literature Parts	14	3936150	Connector,	24	W10012450	Detent Wheel
	W10110850	Use & Care Guide			7-Circuit			(Service Only
	W10110638	Tech Sheet	15	3395683	Connector,			With Illus. 28 )
	W10111226	Guide,			(Motor)	25	W10095960	Harness,
		Quick Start	16	8281225	Screw, 8-18 x 1/2			Communication
			17	2203186	Connector,	26	W10012820	Knob, Spring (2)
					5-Circuit			(Service Only
2	3980634	Top	18	W10031410	User Interface			With Illus. 28 )
3	8579739	Harness, Main			(Center)	27	W10116701	Knob, Control
4	W10116694	Panel, Console			(Includes Item:			(Includes:
		(Includes Items:			13.)			Illus. 21 )
		20,21,22,27,28)	19	W10031420	User Interface	28	280230	Encoder-Wheel
5	3394427	Clip, Harness			(Right)			Kit
6	W10006840	Bracket, Console	20	W10012430	Encoder-Wheel			(Includes Item:
		(Includes No.12)	21	W10012440	Retainer, Snap			23, 24, & 26 )
7	353424	Connector, Sensor	22	W10012410	Knob, Light Ring	29	W10112268	Clip, Harness
8	94614	Terminal			(Includes:	30	3391018	Tie, Cable
9	3936144	Plug, Terminal			Illus. 21 )	31	W10110976	Cube-Cable
10	94613	Terminal	23	W10012810	Rast, Wheel	32	W10117943	Badge
11	3390647	Screw, 8-18 x 1/2			Assembly			
12	W10112267	Foam-Seal			(Service Only			
13	W10030070	Array, Power			With Illus. 28 )			

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

# CABINET PARTS

For Models: WED9200SQ0

(White)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

# CABINET PARTS

For Models: WED9200SQ0

(White)


Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION
1	8576583	Cover, Terminal Block	19	8574875	Assembly, Door Switch	39	3388674	Idle Bracket
2	3390814	Screw, 8-18 x 3/8	20	W10121334	Tri Ring	40	343641	Screw, 10-16 x 1/2
3	697776	Screw, 10-32 x 5/8 (Ground)	21	8066115	Cover-Plate	41	W10133207	Panel, Rear
4	3397659	Block, Terminal	22	8529053	Ramp, Door	42	98129	Screw, 6-20 x 1 1/16
5	3394881	Switch, Broken Belt	23	3407228	Assembly, Power Cube	43	3390647	Screw, 8-18 x 1/2
6	3357011	Screw, 10-16 x 1/2	24	8578450	Panel, Side (R.H.)	44	3387242	Seal, Front Panel
7	8578437	Panel, Side (L.H.)	25	W10118614	Seal, Door Switch	45	3393008	Screw, 10-16 x 1/2
8	3392100	Foot, Dryer	26	3389682	Space-Toe Panel	46	8519459	Clip, Toe Panel
	279810	Foot - Optional (Extended Length Package Of 2) (Not Included)	27	8538263	Motor, Assembly 60 HZ.	47	8519207	Base, Cabinet
9	660658	Clamp, Motor (2)	28	3398948	Wire, Jumper (Broken Belt Switch)	48	8578388	Front Panel
10	3387374	Spring, Idler	29	8578220	Pulley 60 HZ.	49	696144	Strike, Door (2)
11	3389420	Retainer, Idler	30	3387610	Belt, Drive	50	90767	Screw, 8-18 x 3/8
12		Plug, Multivent	31	62825	Clip-S Type	51	8579738	Harness, Digital Interface
	697750	White	32	3387118	Bracket, Motor	52	8563727	Bracket, Control
	3388309	Black	33	279393	Terminal Block Screw Kit (For Terminal Block)	53	W10110641	Control Board
	3388311	Biscuit	34	49026	4" - 90° Elbow	54	W10116271	Toe, Panel
13	3388672	Pulley Assembly	35	W10118470	Cover, Control Bracket	Optional Parts Not Included		
14	279318	Terminal, Brass & Tinned (3) (Includes Illus. 33)	36	8563747	Exhaust Pipe & Bracket	Dryer Exhaust Kit (For Side & Bottom Venting)		
15	8066120	Lever, Snap Switch	37	8563750	Exhaust Pipe (Short)			
16	3394081	Wire, Belt Switch	38	8563749	Exhaust Pipe (Long)	66	279818	White
17	8564132	Sound Panel					279820	Black
18	233520	Washer, Thrust					279925	Biscuit

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

# BULKHEAD PARTS

For Models: WED9200SQ0

(White)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

# BULKHEAD PARTS

For Models: WED9200SQ0

(White)


Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION
1	8575324	Shaft, R.H. Thread	19	8575325	Shaft, L.H. Thread	39	3394986	Spring, Lint
2	3390647	Screw, 8-18 x 1/2	20	690997	Ring, Tri			Screen Door
3	3394984	Door, Lint	21	8536973	Roller, Support	42	8577274	Thermistor
		Screen	22	8563745	Exhaust Pipe	43	487909	Screw, 8-15 x 1/2
4	3406653	Harness, Sensor	23	3394985	Housing, Outlet	44	8544362	Housing, Blower
5	697354	Air Duct Assembly	24	8529007	Plug,	45	8066168	Lint Duct Assembly
6	697813	Seal, Outlet			Rear Bulkhead	46	8544769	Housing-Slot
		Housing	25	W10113138	Complete Drum			Heater Box
7	697814	Seal, Drum Front			Assembly	47	8318314	Kit, Thermal
8	3934666	Nut, 3/8 x 16(R.H.)	26	W10109200	Screw, 11-16 x 3/4			Cut-Off (Includes
10	3402841	Lens,	27	697694	Seal, Drum			Illus. 48)
		Drum Light	28	695240	Screw, 8-18 x 1/2	48	8557403	Thermostat 295°F
11	489463	Screw, 8-18 x 3/8	29	8533971	Screw, 8-18 x 3/8			(146°C) (Hi-Limit)
12	8572105	Clip, Exhaust	30	8519221	Channel Bracket,	49	8544770	Housing-Tab
		Pipe			Rear Bulkhead (2)			Heater Box
13	8066208	Clip-Spring	31	8571651	Bracket, Upper	50	8066099	Bracket,
14	8544771	Heater Element			Rear Bulkhead			Heater Box
15	279457	Terminal Wire	33	3406124	Bulb, Light	51	3387230	Screw, 10-16 x 1
		Kit (For Heater	34	3387223	Electrode, Sensor	52	8544776	Flange-Heater Box
		Element Wiring	35	3977373	Bracket,	53	W10113136	Baffle, Drum
		Harness Repair)			Drum Light	54	8519245	Bulkhead, Front
16	W10001120	Nut, 3/8-16 (L.H.)	36	3403634	Socket Assembly	58	8299979	Grill, Outlet
17	8520836	Bulkhead, Rear	37	697772	Wheel, Blower	60	697770	Seal, Cover Plate
18	3387459	Washer, Support				64	W10049370	Lint, Screen

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

# DOOR PARTS

For Models: WED9200SQ0

(White)



Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION
1	W10085210	Label-Hinge Hole Cover	8	3400224	Screw, 10-16 x 1/2	15	8579662	Gasket, Window
2	8577250	Door Hinge Assembly	9	8578151	Door Assembly (Outer)	16	W10048910	Screw-Plug
3	W10017850	Screw, 10-24 x 3/64	10	8578229	Door Assembly (Inner) (Includes Item: 12 & 25)	17	8566254	Window
4	9742177	Screw, 8-18 x 5/8	11	355515	Screw, 8-18 x 11/16	18	8580116	Pad-Handle
5	8578153	Cover-Hinge (L.H.) (Following Parts Not Included)	12	3398175	Door Catch Assembly (Upper)	19	W10110265	Tear-Drop Trim & Clip Assembly
	8578152	Cover-Hinge (R.H.)	13	8519356	Retainer-Window (Upper)	20	W10074630	Door-Shield
6	W10139457	Seal-Door	14	8519354	Retainer-Window (Lower)	21	8578157	Door Intermediate
7	W10047960	Handle-Ring & Pad Assembly				22	8578156	Door Mask
						23	8578155	Door Screen
						24	3393258	Screw, 10-16 x 1/2
						25	690081	Door Catch Assembly (Lower)
						26	W10129065	Clip, Metal

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

# OPTIONAL PARTS (NOT INCLUDED)

For Models: WED9200SQ0

(White)

Illus. No.	Part No.	DESCRIPTION
---------------	-------------	-------------

## PAINT, TOUCH-UP (1/2oz.)

	72017	White
	72302	Black
	4392899	Biscuit

## PAINT, PRESSURIZED SPRAY (12 oz.)

	350930	White
	786020	Black
	4392901	Biscuit
	350938	Primer, Gray

## PAINT, BULK (1 qt.)

	799344	White (Uncut)
	4392900	Biscuit (Uncut)
	786302	Black (Uncut)

## ACCESSORY PARTS

	8529894	Kit, Hold Down
	8541503	Kit, Stack Assembly
	8579666A	Kit, Door Reversing
	80047	Kit, Dryer Repair
	8521957	Dry Rack